

## Schwalbe Tubeless Easy Fitting Process

Fit the tyre as usual onto the rim. Be cautious when applying the tyre levers. Important: Apply **assembly liquid** to both tyre beads before inflating (1). Make sure the valve is between the beads when inflating (2). Start inflating with a **powerful burst of air** (track pump or compressor) (3). The tyre engages audibly on the rim. Using the rim line, make sure the tyre is properly in place (4).

Deflate the tyre a little. Remove the valve core (valve key is supplied with Doc Blue) and fill in 60 ml of the **puncture protection liquid** Doc Blue (5). For road bike tubes 30 ml is enough.

- Strictly observe the indications regarding maximum inflation pressure of tyre and rim!
- Do not use CO2 cartridges. CO2 has a negative effect on the puncture protection liquid
- Be careful in general when using the sealing liquid. It easily causes stains on clothing or pieces of furniture
- You should only use wheels which are expressly approved by the manufacturer for a tubeless conversion.

